

## **MH TRS**

### **BOM**

MH TRS PCB and Panel

2x 3.5mm Thonkiconn mono Jacks (black)

8x 3.5mm Thonkiconn stereo Jacks (green)

10x Jack nuts

1x dual gang A50k Alpha 9mm potentiometer + nut

1x Potentiometer knob

1x DPDT ON-OFF-ON - Dailywell Sub-mini Toggle Switch with 2 nuts

### **Assembly instructions**

Put one nut on the switch and tighten (this acts as a spacer)

Place the switch, jack sockets and potentiometer on the PCB (Do not solder yet). The two black mono jacks must go in positions J2 and J3.

Put the front panel over all the front panel components. Secure with the pot nut, remaining switch nut and jack nuts

Check that the jacks are still aligned to the PCB and have not been rotated by tightening the nuts. If any of them are out of place loosen the nut adjust and retighten.

Solder everything making sure there is no gap between the front panel components and the PCB.

Put the knob on the potentiometer

Done!