

## **MH Eurorack Dual A/B**

### **BOM**

MH PCB and Panel

6x 3.5mm Jacks

6x Jack nuts

1x DPDT ON-OFF-ON sub-miniature switch with 2 nuts

### **Assembly guide**

Put 1 nut on the switch and tighten (this acts as a spacer)

Place the switch and jack sockets on the PCB (Do not solder yet).

Put the front panel over all the front panel components. Secure with the switch nut and jack nuts

Check that the jacks are still aligned to the PCB and have not been rotated by tightening the nuts. If any of them are out of place loosen the nut adjust and retighten.

Solder everything making sure there is no gap between the front panel components and the PCB.

Done!