

## **MH Bypass**

### **BOM**

MH Bypass PCB and Panel

6x 3.5mm Jacks

6x Jack nuts

2x A100k potentiometer + nuts

2x Potentiometer knob

1x DPDT sub-miniature switch with 2 nuts

### **Assembly instructions**

Put 1 nut on the switch and tighten (this acts as a spacer)

Place the switch, jack sockets and potentiometers on the PCB (Do not solder yet). You might need to very slightly flatten the potentiometer lugs with a small pair of pliers to help place it on the PCB.

Put the front panel over all the front panel components. Secure with the pot nuts, switch nut and jack nuts

Check that the jacks are still aligned to the PCB and have not been rotated by tightening the nuts. If any of them are out of place loosen the nut adjust and retighten.

Solder everything making sure there is no gap between the front panel components and the PCB.

Put the knobs on the potentiometers

Done!